



HOW TO INSTALL MODEL #401

Note: An adaptor should be ordered if this unit is to replace a 10 or 14 inches turbine




STEP 1



Using a drill with the appropriate bit, remove the screws that are securing the turbine head onto the base flashing .

Verify that the base is in good and solid condition as well as the sealant to prevent any rain or snow infiltrations.

STEP 2



Place the ventilator model 401 over the base making sure it is level and that all four louvers pass the peak.

Secure with self-tapping screws provided.

Make sure not to use the original holes.